

117031EN-03 2021-04

Product data sheet

# Nordic S2

#### PRODUCT CODE 800110, 800111, 800112, 800113



Ventilation unit for small houses, single-family houses and small commercial buildings.

### **Product description**

- Balanced ventilation with a good indoor climate
- Very energy-efficient with high efficiency and low SFP value
- Quiet
- Smart control with Flexit GO

## Automatic control

The Flexit GO app is standard for the unit.







(

Google Play App Store

A CI 70 control panel can be ordered as an accessory.

	NOBB	GTIN	Model
800110	54073581	7023678001103	Nordic S2 RER right-hand model with electric battery
800111	54073596	7023678001110	Nordic S2 REL left-hand model with electric battery
800112	54073600	7023678001127	Nordic S2 R R right-hand model without electric battery
800113	54073615	7023678001134	Nordic S2 R L left-hand model without electric battery

## Technical data

		S2 RE	S2 R	
		with electric battery	without electric battery	
POWER	Rated voltage (AC 50 Hz)	230 V	230 V	
	Frequency	50 Hz	50 Hz	
	Fuse size	10 A	10 A	
	Rated current	3,4 A	1,2 A	
	Rated power, total	679 W	179 W	
	Rated power, max. electric battery	500 W	-	
	Rated power, fans	2x83 W	2x83 W	
	Rated power, rotor motor	4 W	4 W	
	IP class*	21	21	
VENTILATION	Fan type	B-wheel	B-wheel	
	Fan motor control	0-10 V	0-10 V	
	Max. fan speed RPM	3 200	3 200	
	Automatic control, standard	Flexit GO	Flexit GO	
	Filter class	ePM1 55% (F7)	ePM1 55% (F7)	
	Filter type (supply air/extract air)	Compact filter	Compact filter	
DIMENSIONS	Filter dimensions (WxHxD)	166x272x48 mm	166x272x48 mm	
	Weight	56 kg	56 kg	
	Kitchen fan connection	Dia. 125 mm	Dia. 125 mm	
	Duct connection	Dia. 160 mm	Dia. 160 mm	
	Height	777 mm	777 mm	
	Width	599 mm	599 mm	
	Depth	537 mm	537 mm	
COATING	Colour	White	White	
	RAL	9016	9016	
	Gloss	25-35	25-35	

NORDIC S2

Energy class:




CTRL 0.65


### LOCAL DEMAND CONTROL

Sensor control for different zones **Accessories:** App + CO<sub>2</sub> sensor/ motion sensor + damper **Result:** Increased air flow rate in zones that need it


\*For installation on a wall (ducts up)

# **Dimensioned drawings**






2




**FLEXIT** 


# FLEXIT.

# Capacity diagram





### Extract air side



Hz	63 Lw(dB)	125 Lw(dB)	250 Lw(dB)	500 Lw(dB)	1000 Lw(dB)	2000 Lw(dB)	4000 Lw(dB)	8000 Lw(dB)	LwA (dBA)
Supply air	5	5	3	-1	-10	-12	-19	-29	
Extract air	10	9	5	-6	-11	-16	-25	-25	
Radiated	-11	-10	-15	-27	-34	-32	-36	-33	-20

3

### Explanation of diagram:

Sound data is specified as sound power level LwA in the capacity diagrams. (This is sound to duct.)

These values can be corrected by means of the table for the different octave bands in order to look at Lw (without adaptation to A band). The correction table for the various octaves is stated in Lw, which means that the Lw values are after conversion of each octave for supply air and extract air.


Radiated sound from the unit must be calculated from the supply air diagram.

# NORDIC S2





### Position


Nordic S units can be installed vertically on the floor/ wall or suspended from the ceiling and can be in hot and cold zones:




On a wall (Mounting supplied with unit.)








On the floor Absorption feet must be fitted (available as an accessory).



Suspended from the ceiling A ceiling mounting must be fitted (available as an accessory).

.



### For more information on topics including installation, wiring diagrams and accessories, see www.flexit.com



