

116550EN-05 2021-04

Product data sheet

Nordic S4

PRODUCT CODE 800130, 800131, 800132, 800133



Ventilation unit for small houses, single-family houses and small commercial buildings.

Product description

- Balanced ventilation with a good indoor climate
- Very energy-efficient with high efficiency and low SFP value
- Quiet
- Smart control with Flexit GO

Automatic control

The Flexit GO app is standard for the unit.









Google Play App Store



NOBB Model GTIN 800130 52944341 7023678001301 Nordic S4 RER right-hand model with electric battery 800131 52944356 7023678001318 Nordic S4 REL left-hand model with electric battery 800132 52944360 Nordic S4 R R right-hand model without electric battery 7023678001325 Nordic S4 R L left-hand model without electric battery 800133 52944375 7023678001332

Technical data

		S4 RE	S4 R	
		with electric battery	without electric battery	
POWER	Rated voltage (AC 50 Hz)	230 V	230 V	
	Frequency	50 Hz	50 Hz	
	Fuse size	10 A	10 A	
	Rated current	7 A	3.5 A	
	Rated power, total	1200 W	400 W	
	Rated power, max. electric battery	800 W	-	
	Rated power, fans	2x115 W	2x115 W	
	Rated power, rotor motor	4 W	4 W	
	IP class*	21	21	
VENTILATION	Fan type	B-wheel	B-wheel	
	Fan motor control	0-10 V	0-10 V	
	Max. fan speed RPM	3,980	3,980	
	Automatic control, standard	Flexit GO	Flexit GO	
	Filter class	ePM1 55% (F7)	ePM1 55% (F7)	
	Filter type (supply air/extract air)	Compact filter	Compact filter	
DIMENSIONS	Filter dimensions (WxHxD)	247x365x31 mm	247x365x31 mm	
	Weight	62 kg	62 kg	
	Kitchen fan connection	Dia. 125 mm	Dia. 125 mm	
	Duct connection	Dia. 160 mm	Dia. 160 mm	
	Height	727 mm	727 mm	
	Width	753 mm	753 mm	
	Depth	610 mm	610 mm	
COATING	Colour	White	White	
	RAL	9016	9016	
	Gloss	25-35	25-35	

NORDIC S4

Energy class:




CTRL 0.65


LOCAL DEMAND CONTROL

Sensor control for different zones **Accessories:** App + CO₂ sensor/ motion sensor + damper **Result:** Increased air flow rate in zones that need it

*For installation on a wall (ducts up)

Dimensioned drawings









🔁 FLEXIT.

Capacity diagram

Supply air side



Extract air side



Hz	63 Lw(dB)	125 Lw(dB)	250 Lw(dB)	500 Lw(dB)	1000 Lw(dB)	2000 Lw(dB)	4000 Lw(dB)	8000 Lw(dB)	LwA (dBA)
Supply air	5	4	2	-3	-7	-8	-16	-23	
Extract air	8	8	6	-5	-13	-15	-24	-26	
Radiated	-8	-13	-18	-27	-32	-29	-33	-36	-21

3

Explanation of diagram:

Sound data is specified as sound power level LwA in the capacity diagrams. (This is sound to duct.)

These values can be corrected by means of the table for the different octave bands in order to look at Lw (without adaptation to A band). The correction table for the various octaves is stated in Lw, which means that the Lw values are after conversion of each octave for supply air and extract air.


Radiated sound from the unit must be calculated from the supply air diagram.

NORDIC S4




Position


Nordic S units can be installed vertically on the floor/ wall or suspended from the ceiling and can be in hot and cold zones:




On a wall (Mounting supplied with unit.)




.






 On the floor Absorption feet must be fitted (available as an accessory).



Suspended from the ceiling A ceiling mounting must be fitted (available as an accessory).



For more information on topics including installation, wiring diagrams and accessories, see www.flexit.com



